



# INFORMATION BULLETIN

## No.007

**TO** : All CCS Lightning Dealers

**DATE** : April 10, 2007

**SUBJECT** : **DISABLE PROCEDURE FOR THE APU**

### **WARNING**

If APU is started with the Start/Stop button on the control panel in the sleeper, the system may attempt to restart APU after a brief moment while the unit resets (if manual emergency shutoff is pulled during warm-up cycle).

To disable APU, remove the 3 relays (starter, preheat, and fuel solenoid) on the APU as noted in figure below:

